


Boogie Bounce Elite & Studio Owner's Manual

Contents

1. Safety Instructions
2. Care and maintenance instructions
3. Assembly Instructions
4. Disassembly Instructions
5. Warranty



Important - Please scan and watch both the assembly and disassembly videos before operating your trampoline.

ASSEMBLY INSTRUCTIONS & WORKOUT ROUTINES



Safety Instructions



1. **Important** - Equipment unsuitable for children under 6 years and children over 6 years must be supervised at all times.
2. **Important** - Children under 14 years must use equipment with safety cover fitted. Please see assembly instructions.
3. Familiarize yourself with the Boogie Bounce Trampoline owner's manual.
4. Watch all safety and instructional introductory videos on the Boogie Bounce App or DVD.
5. The trampoline shall be assembled by an adult in accordance with the assembly instructions and thereafter checked before the first use.
6. This equipment is to be used only in conjunction with the Boogie Bounce fitness programme.
7. Suitable for domestic and commercial.
8. For indoor use only.
9. Misuse of this equipment can cause serious injury and or death.
10. Place the trampoline on a flat and level surface.
11. Do not use mat while wet.
12. Ensure that each Boogie Bounce trampoline and T Bar handle is inspected in accordance with the care and maintenance section of this manual.
13. Ensure that the floor area around the trampolines is free from any trip hazards.
14. Empty pockets and hands before jumping.
15. Do not eat while jumping.
16. Always step on and off the trampoline with great care and if necessary, use the T Bar handle as a balance aid.
17. Do not, at any time subject the T Bar handle to your full body weight. The T Bar Handle is only there as an aid to balance.
18. Do not jump on or off the trampoline as this may cause injury to you or those around you.
19. Overhead clearance is extremely important. Make sure that there is adequate headroom to avoid any possibility of the individual that is bouncing coming into contact with any surface or protrusion from above including ceilings, light fittings, fans, sprinkler systems, support beams or any other high level object.


20. This equipment is to be used only in conjunction with the Boogie Bounce Home Programme App or DVD. Stay within your own abilities. Do not attempt to carry out any moves that you are not confident with. Push down into the mat and keep the bounce low and in beat to the music. Only attempt some of the more dynamic maneuvers when you are confident to do so.
21. Only execute moves on the trampoline as demonstrated on the Boogie Bounce Home Programme App or DVD.
22. Stay within the yellow outer rim of the trampoline mat. This is 64.5cm in diameter.
23. If you feel faint or dizzy immediately stop bouncing and carefully step off the trampoline using the T Bar handle as a balance aid.
24. Always bounce within the centre of the mat. Do not extend out beyond the edge of the mat.
25. The Boogie Bounce trampoline is designed for use by only 1 person at a time. Collision Hazard.
26. No Somersaults.
27. Do not exit by a jump.
28. Make sure that you have an adequate supply of drinking water.
29. The weight limit of the trampoline is 127 kg.
30. Maintain adequate space around the trampoline to ensure that there is no danger of coming into contact with another object or person.
31. Do not use while wearing shoes.
32. It is advised to wear non-slip socks. Bare feet or ordinary socks are not safe due to lack of grip.
33. Always store the Boogie Bounce equipment in a dry storage facility. Do not allow the equipment to get wet.
34. **Important** - Boogie Bounce trampolines have soft rubber feet on the bottom of the legs to avoid causing permanent damage to customers floor covering. However, due to the rubber being soft, it can leave marks on certain types of flooring such as vinyl flooring, light coloured carpet, wooden flooring etc. It is the responsibility of the user to decide if some type of floor protection, such as a mat is required to further protect the flooring. Boogie Bounce will not accept any claims for marked or damaged floor coverings.

Care and Maintenance Instructions


1. Inspect the Boogie Bounce trampoline and T Bar handle before every use of the equipment.
2. Check that all 6 legs and the base section are correctly fitted on the trampoline with rubber feet on each of the legs.
3. Ensure that all legs are inserted correctly and securely as shown in the assembly instructions.
4. Check that the locking pin holding the T Bar to the handle base is fully located and locked in position.
5. Ensure that the two locking pins that fit into the hinge sections on the main trampoline frame are locked in position before stepping onto the trampoline.
6. Check the trampoline mat and replace if there are any tears or rips to the material.
7. Check the trampoline mat and replace if the stitching shows any sign of fraying or damage.
8. Check the trampoline mat for sag and replace if necessary.
9. Check that there are no broken or damaged bungees, springs, bungee or spring clips around the mat perimeter. Replace as necessary.
10. Check the T Bar handle vertical pole has not been bent or distorted.
11. Check for any sharp protrusions that may cause injury.
12. Do not use anti- bacterial sprays or wipes to clean the trampoline mats. It will rot the stitching causing failure of the mat around the securing loops that attach to the frame. Use only plain soapy water to wash the trampoline mat or 'Clean Freek' products, which are not damaging to the mat and can be found on the Boogie Bounce website.
13. The total weight of The Boogie Bounce Elite Trampoline and Handle is 10.2kg. The Studio Trampoline and Handle is 10.5kg.

Assembly Instructions


Step 1: Remove all components from the Boogie Bounce Elite carry case.




Step 2: Assemble handle by using bolt to secure T section to vertical pole using hex key provided.




Step 3: Unfold rebounder to half-folded position.




Step 4: Stand trampoline on its edge and slot legs on. Locate legs into secured position.




Step 5: Once legs are in position this is what you should see.




Step 6: Insert final leg and handle tube section and ensure it is securely in place as shown.




Step 7: Allow to rest half-way open and insert handle.



Step 8: Insert pin to secure handle in place and securely fasten safety clamp. **Clamp only on Elite models. See Below for Studio Model instructions**






For Studio Models Only. Securely fasten the safety screw into place









Step 9:

IMPORTANT STEPS. FAILURE TO FOLLOW INSTRUCTIONS MAY RESULT IN INJURY. Fully unfold trampoline. Stand on edge of frame and use handle to push down. Before removing foot from frame, insert pin to secure in position. **DO NOT REMOVE FOOT FROM FRAME UNTIL FIRST PIN IS INSERTED.**





Step 10: Insert the pin on the other side.







ELITE TRAMPOLINE ONLY

Important - Safety cover must be fitted before equipment is used by anyone under 14 years. Equipment must not be used by anyone under 6 years.


Step 1: Remove handle pole and fit safety cover around the edge of the trampoline frame. Line up the hole in the safety cover with the handle pole tube.

Step 2: Fit safety cover over the handle pole tube and ensure the it is fitted correctly all the way around the frame.

Step 3: Use the ties to fix the safety cover to the trampoline frame. Then insert handle pole back into tube.



Remove Safety Cover Before Disassembling Trampoline. Ensure you attached handle again before starting disassembly process.







IMPORTANT
DISASSEMBLY
INSTRUCTIONS
READ BEFORE USE
FAILURE TO DO SO MAY
RESULT IN INJURY

Disassembly Instructions





**IMPORTANT STEPS TO FOLD TRAMPOLINE.
FAILURE TO FOLLOW INSTRUCTIONS MAY
RESULT IN INJURY.**

- a) REMOVE ONE PIN FROM TRAMPOLINE HINGE.
- b) KEEP ONE FOOT ON BACK EDGE OF TRAMPOLINE FRAME AND HOLD HANDLE WITH ONE HAND WHILE REMOVING SECOND PIN FROM HINGE WITH OTHER HAND. DO NOT REMOVE SECOND PIN WITHOUT FOOT AND HAND BEING IN PLACE AS EXPLAINED.
- c) NEXT, GENTLY PULL HANDLE TOWARDS YOUR BODY. DO NOT REMOVE FOOT FROM FRAME OR REMOVE HAND FROM HANDLE UNTIL THE TRAMPOLINE IS FOLDED.
- d) SEE IMAGES ON NEXT PAGE.



Remove Handle Pin, Handle Pole and all legs, then fold down into final position to complete disassembly. Pack away in carry bag.



Warranty

Boogie Bounce Trampoline/Stability Handle Warranty

Boogie Bounce Holdings Ltd warrants its trampoline/stability handle equipment to be free from defects in design, material and workmanship under normal use and service conditions. The various component parts of the trampoline and T Bar stability handle are warranted against defects as follows:

Elite Trampoline.

A. Steel frame. Twelve (12) months; B. Sewing on stitched jumping mat. Twelve (12) months; C. Clips and bungees. Twelve (12) months.

Studio Trampoline.

A. Steel frame. Twelve (12) months; B. Sewing on stitched jumping mat. Twelve (12) months; C. triangle and springs. Twelve (12) months.

Stability Handle.

A. All Steel sections and welds. Twelve (12) months. B. Locking pins. Twelve (12) months. Note: Foam grips are not included in the warranty.

This warranty only applies if the equipment has been used, maintained, and stored in accordance with the user instructions and owner's manual supplied with this equipment.

All warranty coverage extends only to the original purchaser and begins from the date of purchase. Boogie Bounce's obligation under this warranty is limited to replacing or repairing the equipment, or refunding the price paid, at Boogie Bounce's option.

If you want to make a warranty claim or contact customer services you must contact Boogie Bounce Holdings Ltd by email: info@boogiebounce.co.uk or by telephone: 0044 [0] 121354 1190. Our trading address is Unit 43, Greendale Farm, Tamworth, Staffordshire, B79 9DJ. If Boogie Bounce requires you to return the equipment to one of its authorised service centers,

you must do so promptly freight prepaid and accompanied by proof of original purchase e.g. order confirmation. Boogie Bounce will assess the claim promptly and will communicate with you using details you have provided to Boogie Bounce. All returns must be preauthorized by Boogie Bounce.

This warranty does not extend to any damage to equipment caused by or attributable to: (a) abuse, misuse, willful damage, negligence, failure to follow the user instructions and owner's manual, improper or abnormal usage or storage; (b) fair wear and tear; and (c) repairs or alterations not provided by or authorized by Boogie Bounce.

No other warranty beyond that specifically set forth above or in Boogie Bounce's terms and conditions of sale is authorised by Boogie Bounce. Please refer to the terms and conditions of sale relating to the sale of the equipment.

Use of any trampoline exposes the user to the risk of serious injury, including permanent paralysis or even death from landing on the back, neck or head. The trampoline must not be used without the T Bar Stability Handle securely attached.

Use of the equipment should always be under the direct supervision of a qualified Boogie Bounce instructor or in conjunction with the Boogie Bounce home exercise videos. Always follow the instructions and warnings provided with your trampoline/stability handle.

Imported by Boogie Bounce Holdings Ltd
Unit 43, Greendale Farm, Burton Road, Elford, Tamworth, Staffordshire, B79 9DJ
Copyright 2021. Boogie Bounce Holdings Ltd.